


950106-02156

DEVELON



Parts Book

Mobile / Tablet Support



USER MANUAL

The information contained in this document is CONFIDENTIAL and PROPRIETARY. No part of this document may be reproduced or transmitted in any form or for any Purpose without the express permission of HD Hyundai Infracore.

1. Log in / Register / Change Password

2. Main

3. Search

4. Parts Catalog



5. Parts Quotation

6. Notice

7. Q&A

8. Settings



1. Log in



| Log in | |
|--------|--|
| 1 | Choose a preferred language. |
| 2 | Enter your email and password. |
| 3 | Tap “Log in” to display the home page. |
| 4 | If you have forgotten your password, you can reset your password through email verification. |
| 5 | Go to the sign-up page. |



| Parts Book Update | |
|-------------------|---|
| 6 | Check the progress of downloading the latest version of the parts book. |
| 7 | If the network connection is unstable, you can try to download again. |

1. Log in - Register





| Register | |
|----------|--|
| 1 | Go to the previous page. |
| 2 | Select your machine location. |
| 3 | Enter your email address. Provide an accurate email address as email verification will be used to reset your password. |
| 4 | Enter your password. Your password must be at least eight characters. |
| 5 | Go to the previous page. |
| 6 | Enter the serial no. for validation. You can scan the serial no. automatically with your camera. |
| 7 | Check the box if you agree with the terms of use . You cannot sign up if you disagree with the terms. |
| 8 | Complete the sign-up process; go to the parts book download page. |

1. Log in – Change Password





| Change Password | |
|-----------------|---|
| 1 | Go to the previous page. |
| 2 | Enter your email address to receive a validation code. |
| 3 | Enter the validation code received via email. |
| 4 | Enter your new password. Your password must be at least 8 characters . |
| 5 | Confirm your new password. |
| 6 | Complete your password reset. |

2. Main – Home / Menu



| Main – Home / Menu | |
|--------------------|--|
| 1 | Open the menu. |
| 2 | Go to the search page. |
| 3 | This indicates the number of parts books that need updates. Tap the button marked with a red square on the right to proceed with the update. |
| 4 | Swipe left or right to view a machine. Tap the machine to view its parts book, or register a new machine. |
| 5 | View the list of recently viewed parts. |
| 6 | Check the spare parts list of the selected machine. |
| 7 | Tap the menu to go to your desired page. |
| 8 | Tap to log out. |

2. Main - Home





Main - History

- The list gives your history of recently viewed parts.
- Tap your desired item to view its parts catalog.
- Go to the home page.
- Go to the spare parts list page.

Main - Spare Parts List



- Go to the home page.
- Tap to view the spare parts list specific to your selected machine.
- You can zoom in/out to view details.

3. Search





| Search | |
|--------|---|
| 1 | Select a machine. |
| 2 | Enter a search keyword (at least two characters). |
| 3 | Check the figure search results for the keyword. |
| 4 | Check the parts search results for the keyword. |
| 5 | Tap the search result to view its parts catalog. |

4. Parts catalog





| Parts Catalog | |
|---------------|---|
| 1 | Select a model. |
| 2 | Select a group. |
| 3 | Select a figure to view its drawing and parts list. |

4. Parts catalog





| Parts catalog | |
|---------------|---|
| 1 | You can check other figure drawings of the selected group. |
| 2 | You can zoom in/out the drawing. |
| 3 | You can view the drawing in full screen mode using the Full screen button . |
| 4 | You can drag up and down to adjust the height of the list area. |
| 5 | You can check the list of parts in the drawing. Touch the part to see the detailed information. |
| 6 | You can check the location information of the selected part configuration. |
| 7 | You can check the detailed information of the selected part. |
| 8 | You can add the selected part to your cart. |
| 9 | Go to the Parts quotation screen. |
| 10 | You can check the detailed information of the selected part. |

5. Parts quotation



| Parts quotation | |
|-----------------|--|
| 1 | You can check your shopping basket list. |
| 2 | You can check the quotation request list. |
| 3 | Select a part to request a quote. |
| 4 | The button provides the option of modifying the quantity of the selected part or deleting the selected part. |
| 5 | Clear the shopping basket list. |
| 6 | Request a quotation for the parts selected in 3). |
| 7 | Input the information to request a quote. |
| 8 | Select a dealer that will create a quote. |
| 9 | Tap Confirm to request a quote. |



5. Parts quotation



Parts quotation



- 1 You can check your shopping basket list.
- 2 You can check the quotation request list.
- 3 Select a quote request item.
- 4 You can check the detailed information of the quote request.
- 5 Order Status can be Requested, Quoted, Confirmed, Ordered, Order Processing, or Cancel by expiry.
- 6 Tap Confirm to accept the quote created by the dealer (Order Status: Quoted).

6. Notice




| Notice | |
|--------|--|
| 1 | Choose the notice category you would like to view. |
| 2 | Tap on a title. |
| 3 | View the notice content. |
| 4 | Tap an attachment to view it. |

7. Q&A




| Q&A | |
|-----|---|
| 1 | Go to the screen where you can input a question. |
| 2 | Select the category of your question. |
| 3 | Check the question you have entered. |
| 4 | Select the category of the questions you're entering. |
| 5 | Input the information on the questioner. |
| 6 | Select a dealer to answer. |
| 7 | Input the title and content of the question. |
| 8 | Save the question you have entered. |
| 9 | You can view the question selected in 3). |

8. Setting




| Settings | |
|----------|--|
| 1 | Change your account information. |
| 2 | Check the history of the Partbook Download. |
| 3 | Register and delete equipment. |
| 4 | Register and delete favorite dealer. |
| 5 | Change your preferred language. |
| 6 | View FAQs for the parts book app. |
| 7 | Check the app version. |
| 8 | View the terms of use. |
| 9 | You may sign off. If you sign off, all information of registered machines will be deleted. |
| 10 | Tap to log out. |

8. Setting > Profile



| Settings > Profile | |
|--------------------|---|
| 1 | Enter your name. |
| 2 | Enter your phone number. |
| 3 | Enter your address. |
| 4 | Search location information through GPS sensor. |
| 5 | Save your updated profile. |

8. Setting > Parts book download history




Settings > Change profile

- 1 Select the parts book to download.
- 2 Download the selected parts book.

* If the registered member installs the App again, Parts book can be downloaded using the Parts book download history information.



8. Setting > Manage My Machine > Register



Settings > Manage My Machine > Add

- 1 Go to the machine registration page.
- 2 Enter the serial no. for validation.
- 3 You can scan the serial no. automatically with your camera.
- 4 Add a machine to download the latest version of its parts book.
- 5 View the list of registered machines.


8. Settings > Manage My Machine > Delete



Settings > Manage My Machine > Delete

- 1 Go to the machine deregistration page.
- 2 Select a machine you would like to delete from the list.
- 3 Delete a machine.

8. Setting > Favorite Dealer



Setting > Favorite Dealer

- 1 Input the dealer phone number to register the dealer in the favorites.
- 2 Finishes searching and registering a dealer phone number.
- 3 Shows the detailed information on the favorite dealer.
- 4 Deletes the favorite dealer

8. Setting > FAQ

